

INTERLOCK SWITCH NO.2

INSPECTION

BA00B-02

CHECK CONTINUITY

Using an ohmmeter and magnetic hand, check continuity between the terminals.

Magnetic hand	Specified condition
Closed by	Continuity
Far away	No continuity

If the continuity is not as specified, replace the switch.